



Кровать Раут




PROXSON

правила хорошего сна



* 80-90



** 120-180

Φ1 Φ2



x16



x44*
x52**

Φ3



x6**

Φ4



x6**

Φ5




x6**

Φ6




x8

Φ7



x2**

Φ9




x2**

Φ8



x14*/28**

Φ10




x6

Φ11




x14

Φ12




x3**



A1

x1


A2
x2





Направление ворса (левая)


Направление ворса (правая)

A3
x1







2




3




4 ** 120-180




5 ** 120-180




6 ** 120-180




7 120-180**



8* 80-90





9 120-180**



10

*** 80-90**



**** 120-180**

